



Bottom holder

There is nothing special about this part, it just locks together the back and front support shells together via four M2.5x8mm screws.



It will show again the wrong direction for printing, so please make sure you rotate via Y axis and position on the bed properly.



Preparation and Assembly


Not much preparation needed before mounting to the shell.



Except maybe pre-drilling the holes with 2.5mm drill bit



Finally screw the four bolts while holding the panels together



73, Chris
M0NKA